

**3M** Science.  
Applied to Life.™



# Respiratory Protection.

## 3M™ Qualitative Fit Test Apparatus

The 3M Qualitative Fit Test Apparatus offers a simple way to comply to the requirements of AS/NZS1715:2009 qualitative fit testing requirements. It can be used to assess the face-to-respirator seal of any particulate respirator or gas/vapor respirator with a particulate prefilter.

Fit testing must be performed before a respirator is first issued to a worker and is required annually thereafter. (Note: a separate user seal check must be performed each time the respirator is worn.)

Fit testing is accomplished by spraying a test agent into the hood environment with the respirator in place. If the wearer does not detect the taste of the test agent, an acceptable fit has been demonstrated.

#3MScienceOfSafety

# 3M™ Qualitative Fit Test Apparatus

## Benefits

- Fast, easy method for performing qualitative fit testing
- Two test agent options are available to determine employee's taste threshold to test solution
  - 3M™ Qualitative Fit Test Apparatus FT-10, Sweet and
  - 3M™ Qualitative Fit Test Apparatus FT-30, Bitter
- Can be used with any particulate respirator, or any gas/vapor respirator with particulate prefilter
- Convenient, reliable and economical to use
- Provides consistent test atmosphere for test exercises
- Educational material available from 3M to help you meet AS/NZS1715:2009 respirator program requirements



## Ordering Information

	Cat. Number	3M Ordering Code	Description	Size	Item/Box	Box/Case
	FT-10	70070121515	3M™ Qualitative Fit Test Apparatus (sweet) 11 Contains: FT-11, FT-12, FT-14, FT-15 (1 each); FT-13 (2 each)		1	1
	FT-30	70070709640	3M™ Qualitative Fit Test Apparatus (bitter) 11 Contains: FT-31, FT-32, FT-14, FT-15 (1 each); FT-13 (2 each)		1	1
	FT-11	70070121457	Sensitivity Solution (sweet)	55 mL	1	6
	FT-12	AT019167397	Fit Test Solution (sweet)	55 mL	1	6
	FT-31	AT010587395	Sensitivity Solution (bitter)	55 mL	1	6
	FT-32	AT010587403	Fit Test Solution (bitter)	55 mL	1	6
	FT-13	AT019167058	Nebulizer		1	3
	FT-14	70070121481	Test Hood (2/pack)		2	5

For additional information on all 3M™ Qualitative Fit Test Apparatus, visit:  
[www.3M.com.au/ppesafety](http://www.3M.com.au/ppesafety) (Australia) or [www.3M.co.nz/ppesafety](http://www.3M.co.nz/ppesafety) (New Zealand)



**Personal Safety Division**  
**3M Australia Pty Ltd**  
 Bldg A, 1 Rivett Road  
 North Ryde NSW 2113

**3M New Zealand Ltd**  
 94 Apollo Drive, Rosedale  
 Auckland 0632

TechAssist Helpline 1800 024 464  
 Customer Service 1300 363 565  
 Email [techassist@mmm.com](mailto:techassist@mmm.com)  
 Web [www.3M.com.au/ppesafety](http://www.3M.com.au/ppesafety)

TechAssist Helpline 0800 364 357  
 Customer Service 0800 252 627  
 Email [3mzitm@mmm.com](mailto:3mzitm@mmm.com)  
 Web [www.3M.co.nz/ppesafety](http://www.3M.co.nz/ppesafety)

3M is a trademark of 3M.  
 © 3M 2018. All rights reserved.  
 AV011467782